



Dimenzije akumulatora



**SD 01
SD 02**


a



**SB 01
SB 02
SB 03
SB 04
SB 05
SB 06**


**Priključni
polovi 3**

b




**SC 01
SC 02**

c




**SD 01 SD 07 GD 01
SD 02 SD 08 GD 02
SD 03 SD 09
SD 04 SD 10
SD 05
SD 06**

d




**SE 01 SE 08 UE 01
SE 02 GE 01 UE 02
SE 03 GE 02
SE 04 GE 03
SE 05
SE 06
SE 07**

e




**SF 01
SF 02
SF 03
SF 04**

f




GG 01 **SG 01**
GG 02 **SG 02**
SG 03
SG 04
UG 01 **SG 05**
UG 02 **SG 06**
SG 07
SG 08

g





SH 01
SH 02
UH 01
UH 02

h



SI 01
SI 02



i



- SK 01
- SK 02
- SK 03
- SK 04
- SK 05
- SK 06

- UK 01
- UK 02



j



- SJ 01
- SJ 02
- SJ 03
- SJ 04
- SJ 05
- SJ 06

- UJ 01
- UJ 02

k



- SL 01
- SL 02
- SL 03
- SL 04
- SL 05
- SL 06
- SL 07
- SL 08
- UL 01
- UL 02
- UL 03
- UL 04
- UL 05
- UL 06

l